

GWM Poer 2019 Acrylic Bonnet Protector Installation Instruction (COMMERCIAL)



IMPORTANT: Ensure that the clips are positioned over anti-abrasive tape and does not come into contact with any of the bonnet's paint work. Failure to do so may result in permanent paint damage.

1. Position the No.2 metal clips as the pics showed



2. Position the No. 1 Metal clips as pics showed.



3. stick the NO.3 rubber bumper under the bonnet guard at the positon of no.3.

