



Our wood-veneer wall slat panels offer countless possibilities to creatively design your interior and to set natural accents. The panels are made with a unique sound absorbing felt.


In our assortment you will find four wood grain finishes: PINE, GREY, CHARCOAL & SILVER ASH.

Whether you prefer a modern luxurious interior or a modern style, our wall panels can be adapted to any decor.

## THE INSTALLATION IS AS EASY AS 1-2-3!

### TOOLS REQUIRED:

 Panel or Construction Adhesive

 Measuring tape

 Black (recommended) 1 1/2" screws

 Utility knife

 Level & Pencil

 Drill

 Music - it's an enjoyable project

 Miter saw with finishing blade

**NOTE:** If you plan on mounting directly onto drywall only, insert the necessary wall plugs in order to properly secure the black screws.

### PREPARATION:

Prepare and inspect the wall by making sure the entire surface is in good condition, smooth, clean and dry. It is recommended to use 6-8 screws per panel. Spaced evenly around the edges of the panel.

#### Step 1

Measure the surface area and draw guidelines with the help of the Level to ensure a successful installation.

#### Step 2

Cut the first wall panel to size to the desired height, using a miter saw with a finishing blade. Run a thin bead of panel or construction adhesive 1" (2.54cm) from all four edges and middle of the panel. Position panel on the wall and ensure it is straight and level.

#### Step 3

Using black screws secure the panel onto the wall. Slide the second panel into the first panel and ensure it is flush with the edge of the panel. This helps ensure a seamless finished look. Repeat until desired area is covered.

**NOTE:** Black felt can be easily trimmed with a utility knife.