



Our polystyrene wall slat panels provide a gateway to a world of boundless possibilities. With these panels, you can creatively transform your interior.

Whether you prefer a luxurious interior or a modern style, our wall panels can be adapted to any decor. From small profiles to higher profile wall panels, there really are no limits.

Panel Upp decorative wall slat panels are manufactured with the highest quality environmentally friendly material.

THE INSTALLATION IS AS EASY AS 1-2-3!

TOOLS REQUIRED:

 Panel or Construction Adhesive

 Measuring tape

 18-Gauge Finishing Nails

 Level & Pencil

 Finish nailer

 Miter saw with finishing blade

PREPARATION:

Prepare and inspect the wall by making sure the entire surface is in good condition, smooth, clean and dry.

Step 1

Measure the surface area and draw guidelines with the help of the Level to ensure a successful installation.

Step 2

Cut the first wall panel to size to the desired height, using a miter saw with a finishing blade. Run a thin bead of panel or construction adhesive 1" (2.54cm) from all four edges and middle of the panel. Position panel on the wall and ensure it is straight and level.

Step 3

Using a headless nail gun, secure panel on wall using 18-gauge finishing nails. Slide second panel into first panel and interlock. This helps ensure a seamless finished look. Repeat until desired area is covered.