

Replacing Bushings & Roller Bearings In Pneumatic and No Flat Wheels (8"x2.0", 8"x2.5", 10"x3")

Models manufactured between 2000 and 2008 used a 20mm axel. After 2008 all 8" and 10" wheels use a 19mm axel. If your replacement wheel is tight and doesn't turn freely do the following: Using a wrench handle or rounded rod, pop the bushings out of the old wheel and new wheel as shown (its easy). Press the old bushings into the new wheel hub and install wheel on axel. The wheel should now turn easily on the axel.



Bushing

Roller Bearing

Bushing



R-Trac 10"x3" wheel with 19 mm bore



R-Trac 8"x2.0" wheel with 19 mm bore