



Concept7 Carbon Fiber A-Pillars Installation Instructions P/N NAD-CFAP

1. Open door on vehicle and remove lower front screw at the base of the a-pillar. (repeat all the below steps for passenger side)
2. Carefully pry bulb seal away from a-pillar starting from the bottom allowing for it to hang at the top.
3. Once you have bulb seal loose, remove the other 6 screws. Once these screws are removed carefully remove the a-pillar.
4. Now that you have removed the a-pillar drill out the (4) 3/16 rivets holding the aluminum channel that holds the bulb seal. Save channel to be used on the new carbon fiber pieces.
5. Rivet aluminum channel to carbon with 3/16 rivets
6. Re-assemble re-using screws and push back in bulb seal so it's securely in place.
7. Follow all above instructions for opposite side.

For photos & additional information, please see our [web site](#). For technical support with this product, please email us at info@nowickiautosport.com