

Concept7 Splitter P/N NAD-CFFS Installation Instructions

PROFESSIONAL INSTALLATION RECOMMENDED

1. Before installing your new carbon front splitter and rocker panels, the following tools are required: 1/8, 3/16, 23/64 drill bits, drill motor, rivet gun, M6 thread setter, 7mm socket and 10mm socket.
2. Raise the car on a lift of four jack stands.
3. Remove the 10 7mm screws on the bottom of the front fascia.
4. Attach carbon splitter with a few of the 7mm screws to locate the four new attachment locations forward of the existing 7mm screws. Visually align the splitter at the bottom of the fascia, so it



looks properly positioned in relationship to the car.

5. Using the 1/8 drill bit, make pilot holes through the existing four holes in the splitter into the front fascia.
6. Use the 23/64 drill bit and open up the 1/8-inch holes the fascia.
7. After locating and drilling the four new mounting points, insert the M6 nut-sert and crimp tightly. The nut-sert should not be loose.
8. Install the splitter using the factory 7mm screws and 10 provided washers. **DO NOT** tighten all of the fasteners until the splitter has been properly aligned (Step 4). Tighten the fasteners starting with the 7mm screws, followed by the M6 bolts. **DO NOT OVER-TIGHTEN.**

