



Concept7 Carbon Fiber Fuel Rail Covers
P/N NAD-CFSC Installation Instructions
Professional Installation Recommended

1. This product is designed to be bonded to the existing factory fuel rail cover
2. Rough up original fuel rail cover with 80 or more grit sandpaper to promote good adhesion
3. Purchase high temp 2 part epoxy from hardware or auto parts store
4. After you have roughed up bonding surface clean thoroughly with lacquer thinner to remove any oil or any other substance
5. Use a significant amount of epoxy to bond carbon fiber units to factory fuel rail covers
6. Let cure to specifications of epoxy and install

For photos & additional information, please see our web site. For technical support with this product, please email us at info@nowickiautosport.com.