

FERRO CONCEPTS - ADAPT FRONT FLAP BUCKLE KIT INSTALLATION

INSTRUCTIONS APPLY TO ALL FERRO CONCEPTS ADAPT FRONT FLAPS WITH G-HOOKS



1. THREAD THE END OF THE 1" ONE-WRAP VELCRO ALL THE WAY THROUGH THE BACKSIDE OF THE G-HOOK AS SHOWN.



2. THREAD THE END OF THE 1" ONE-WRAP VELCRO ALL THE WAY THROUGH THE TOP OF THE NEXT SLOT OF THE G-HOOK.



3. PULL THE ONE-WRAP TIGHT AND ADHERE IT TO THE HOOK VELCRO ON THE BACKSIDE OF THE ADAPT FRONT FLAP.



4. REPEAT SET 1-3 FOR THE OPPOSING SIDE. CONFIRM YOUR INSTALLATION LOOKS LIKE THE PHOTO ABOVE. THE FRONT FLAP CAN NOW BE INSTALLED TO A BUCKLE EQUIPPED CARRIER.