

INSTALLATION OF QASM BUCKLES

FOR BUCKLE TOP FERRO CONCEPTS FRONT FLAPS

QASM BUCKLES INSTALLED ON FERRO CONCEPTS PLATE CARRIERS MAY BE COMPATIBLE WITH FLAPS/ POUCHES FROM OTHER COMPANIES. FERRO CONCEPTS **DOES NOT** GUARANTEE FITMENT OF NON FERRO CONCEPTS PRODUCTS.



1. INSTALL TOP BUCKLE BAR INTO UPPER VERTICAL MOLLE SLOT ON THE FRONT OF THE CARRIER.



2. INSTALL BOTTOM BUCKLE BAR INTO LOWER VERTICAL MOLLE SLOT ON THE FRONT OF THE CARRIER.



3. WHEN INSTALLED CORRECTLY, BUCKLE BARS SHOULD BE FULLY SEATED IN THE VERTICAL MOLLE SLOTS.



4. REPEAT STEPS 1-3 ON THE OPPOSING SIDE. ENJOY.