


Walnut combines thoughtful modern design with old-world craft.


walnutstudiolo.com
503.447.6889

“The Burnside” Leather Drawer Pull (Small, Large) Installation Instructions

- Gather your tools: drill, screwdriver, ruler, pencil.
- Measure out where you want the handle to go and hold the handle up to the drawer or door face to mock it up. Mark the spot where the hardware will go with a pencil.
- Drill a pilot hole at the mark using a 1/8” drill bit. Using the pilot hole as the center, next drill a hole using 7/32” drill bit.
- Insert the Chicago screw (surfaceless head) into the hole you drilled in the door/drawer.
- The hardware provided includes 2-4 back screws of different lengths for doors and drawers of differing widths. Choose the back screw that fits your project the best.
- Secure the pull by inserting and tightening the chosen back screw into the Chicago screw on the backside of the door/drawer. Nicely done!!



We'd love to see pictures of your installations! Share them with us at walnutstudiolo@gmail.com, or find us on social media as [@walnutstudiolo](https://www.instagram.com/walnutstudiolo)



What to do with that extra hardware?

We include duplicate hardware with your handle for max flexibility. Instead of throwing away, you could:
a) keep it for future use, in case you want to move the handles, b) recycle it with mixed metals, or
c) mail it back to us for re-use: Walnut Studiolo - Reuse Program, 36005 Hwy 53, Nehalem OR 97131.



walnut




Walnut combines thoughtful modern design with old-world craft.


walnutstudiolo.com
503.447.6889

“The Burnside” Leather Drawer Pull (Small, Large) Installation Instructions

- Gather your tools: drill, screwdriver, ruler, pencil.
- Measure out where you want the handle to go and hold the handle up to the drawer or door face to mock it up. Mark the spot where the hardware will go with a pencil.
- Drill a pilot hole at the mark using a 1/8” drill bit. Using the pilot hole as the center, next drill a hole using 7/32” drill bit.
- Insert the Chicago screw (surfaceless head) into the hole you drilled in the door/drawer.
- The hardware provided includes 2-4 back screws of different lengths for doors and drawers of differing widths. Choose the back screw that fits your project the best.
- Secure the pull by inserting and tightening the chosen back screw into the Chicago screw on the backside of the door/drawer. Nicely done!!



We'd love to see pictures of your installations! Share them with us at walnutstudiolo@gmail.com, or find us on social media as [@walnutstudiolo](https://www.instagram.com/walnutstudiolo)




What to do with that extra hardware?

We include duplicate hardware with your handle for max flexibility. Instead of throwing away, you could:
a) keep it for future use, in case you want to move the handles, b) recycle it with mixed metals, or
c) mail it back to us for re-use: Walnut Studiolo - Reuse Program, 36005 Hwy 53, Nehalem OR 97131.



walnut



Cabinet surface

Chicago screw
(with internal
threading)



Back screw
(different lengths
for different
cabinet widths)

Cabinet surface

Chicago screw
(with internal
threading)



Back screw
(different lengths
for different
cabinet widths)