

OSGIKEN

Side Bearing Shim Reference for

OS Giken [987] Porsche Cayman 6spd MT LSD Installation



Instructions

1. For installation into Porsche 987 Cayman 6spd manual transmission, please use the included 3mm shim prior to installing side bearings. The shim is to be placed on the bearing flange on the “long” side of the differential. Please reference the above pictures for orientation.

General Warning

Please be aware of the potential risks and hazards when installing aftermarket products. We do not take any responsibility for any loss and/or injury that may occur when our products are modified, re-used, or installed incorrectly. Please seek a trained professional for installation of our products.