



## Extended Diffuser Fins - MK7.5R Installation Instructions

### NOVUSTECH:

 [@novustech](https://www.instagram.com/novustech)

 [@novustechspacers](https://www.facebook.com/novustechspacers)

 Kitchener, Ontario, Canada

### Time:

- 5-10 minutes

### Tools required:

- Power drill with #2 phillips bit

## WHAT IS INCLUDED:



## Instructions:

- Step 1: Place fin over factory fin and push towards the front of the car until fin stops.
- Step 2: Insert one of the provided self tapping screws into the fin hole at the bottom and use a drill to mount the fin. NOTE: be careful to not overtighten and strip the hole.
- Step 3: Repeat for remaining fins

NOTE: alternative to Step 2, you can drill a pilot hole with a 1/16" (1.5mm) drill and then use a screwdriver by hand to mount each fin



## Materials

- Diffuser Fins are 3D Printed out of ABS Plastic
- Hardware is made of 304L SS

## Additional Resources:

### Visual Examples:

<https://i.redd.it/55iv3oacrn41.jpg>

[https://www.instagram.com/p/B-xSOC8nD1r/?utm\\_source=ig\\_web\\_copy\\_link](https://www.instagram.com/p/B-xSOC8nD1r/?utm_source=ig_web_copy_link)

### Instagram Customer Review:

[https://www.instagram.com/p/B\\_ih4a8nTUC/?utm\\_source=ig\\_web\\_copy\\_link](https://www.instagram.com/p/B_ih4a8nTUC/?utm_source=ig_web_copy_link)