

POLARIS Ranger General 1000 from 2016 (TBW)

Parts list for MCS 2770a TBW

<u>Item</u>	<u>Qty</u>	<u>Part Number</u>	<u>Description</u>
1	1	MCS 8000C TBW	Computer
2	2 lengths		Velcro mounting tape 7cm long
3		<u>MCS 2774-835F</u>	<u>Control Switch assembly with OPTIONAL spray switch</u>
	1	MCS 822-160	Control Switch
	4		4 gauge x 1/2" pan head self-tap screws
	1	MCS 835F	Switch bracket with spray switch
	1	MCS 823-160	Spray switch
		<u>OR</u>	
4		<u>MCS 2774-836F</u>	<u>Control Switch assembly without spray switch</u>
	1	MCS 822-160	Control Switch
	4		4 gauge x 1/2" pan head self-tap screws
	1	MCS 836F	Switch bracket without spray switch
5	2		8g x 1/2 self-tapping screws
6	2		4mm flat washers
7	1	<u>MCS 2771 R1</u>	<u>Wiring harness</u>
a			Computer plug (26 pin)
b			Cruise Control Power Fuse (3 amp fuse)
c			Power connector (to vehicle accessory power)
d			Gear position sensor connectors (white wires)
e			Speed sensor connectors (green/red wires)
f			Brake switch connectors (red & orange wires)
g			Connectors for optional Spray power harness (pink & blue wires)
h			Control switch plugs (6 way & 3 way)
8	1	MCS2771 TPH	Throttle Pedal Harness
		<u>OPTIONAL</u>	
		<u>MCS 2770SPK</u>	<u>Spray Power Kit</u>
9	1	MCS 2771SPH	Spray Power Harness
10	1	JD 045M	Spray Power Socket
11	2	H 2832	Terminals for above
12	3		8g x 3/8 self-tapping screws (relay/power plug mount)
	1		M5 x 16 pan head screw (relay mount)
	1		5mm flat washer (relay mount)
	1		M5 Nyloc nut (relay mount)
13	1	JD 045M	Spray Power Plug
14	2	H 3555	Terminals for above
	1		Dress Makers Pin (terminal extractor tool)
	1		Paperclip (computer terminal insertion tool)
	10		1500mm cable ties
	10		200mm cable ties
	10		300mm cable ties
			Information, Set up and Operation Manual
			Operation and User Manual
			Installation Manual
			Trouble shooting guide

