

HONDA CRF1000 & CRF1000D DCT from 2018 (Throttle By Wire)

Parts list for MCS 6710TBW kit (manual shift)

Parts list for MCS 6710TBW DCT kit (DCT shift)

<u>Item</u>	<u>Qty</u>	<u>Part Number</u>	<u>Description</u>
1	1	MCS 8128TBW	Computer
2	2 lengths		Self-Adhesive Velcro 8cm long
		<u>MCS 6384</u>	<u>Control Switch assembly</u>
3	1	MCS 820-160	Control Switch
4	1	MCS 8310	Switch bracket
	4		4 gauge x 1/2" pan head self tap screw
5	1	<u>MCS 6713TBW</u>	<u>Wiring harness (manual shift)</u>
OR	1	<u>MCS 6711TBW DCT</u>	<u>Wiring harness (DCT shift)</u>
a			Computer plug (26 pin)
b			Fuse holder (3 amp fuse)
c	(only manual shift)		Tach sensor (yellow wire)
d			Speed sensor (pink wires)
e	(only DCT shift)		Neutral sensor (blue wires)
f			Power & brake sensor plugs (orange and grey wires)
g	(only manual shift)		Clutch sensor (blue wire)
h			Control switch plug (6 pin)
6	1	<u>MCS 6711TPS</u>	<u>Throttle Position Sensor Wiring Harness</u>
a			Computer plug terminals
b			TPS connectors

OPTIONAL

10cm	HST3	Terminal extractor tools
1		3mm heat shrink tube
10		Wire paper clip (terminal insertion tool)
10		100mm cable ties
10		150mm cable ties
6		200mm cable ties

Information, Set up and Operation Manual

Operation and User Manual

Installation Manual

Trouble shooting guide

