

# BMW F800GS from 2016 (Throttle-by-Wire)

## Parts list for MCS 7010\_R1 kit

<u>Item</u>	<u>Qty</u>	<u>Part Number</u>	<u>Description</u>
1	1	MCS 7010 TBW	Computer
2	2 lengths		Self-Adhesive Velcro 8cm long
3	1	MCS GT1014-160	Control Switch
	8cm		Foam mounting tape
	2		300mm cable ties
OR			
		<u>MCS 7014-830W</u>	<u>Optional Mirror Mount Control Switch Assembly.</u>
4	1	MCS 820-160	Control Switch
5	1	MCS 830W	Switch bracket
	4		4-gauge x 1/2" pan head self-tap screw
6	1	<u>MCS 7011 R1</u>	<u>Cruise Control Wiring Harness – no CAN-BUS dongle patch</u>
<u>OR</u>			
7	1	<u>MCS 7013 R1</u>	<u>Cruise Control Wiring Harness with CAN-BUS dongle patch</u>
a			Computer plug (26 pin)
b			Fuse holder (3 am fuse)
c			CAN-BUS connector/s (white/black and white/brown wires)
d			Control switch plug (6 pin)
e			TPS connectors (green, brown and black wires)
f			Brake sensor connectors (grey wires)
g			Power connector (red or red/green wires)
	20cm	HST3	3mm heat shrink tube (harness connections)
	20cm	HST4	4mm heat shrink tube (harness connections)
	5		100mm cable ties
	5		150mm cable ties
	5		200mm cable ties
	5		300mm cable ties
			Information, Set up and Operation Manual
			Operation and User Manual
			Installation Manual
			Trouble shooting guide

