



# C7 HP RADIATOR

## 32-1149114M INSTALLATION INSTRUCTIONS

The hood duct and fan shroud must be modified to allow for our HP (70mm) core installation. The following five (5) images illustrate the trimming required.

Note: Only the bottom 2/3 of the hood duct is going to be cut back 1/2". Cut through front face 1/2" deep only.



Cut 1/2" off from this point to opposite side.



Sharpe offers a silver color marker that helps when working with dark items.



Finish cut along the bottom. You will cut through the foam seal on the bottom. Try to keep the remaining seal intact.



Cut this raised portion off completely.

Cut back 1/2" all around the shroud. Leaving flanges on both left and right sides.