

Universal Mounting Instructions



1. Prepare the application area of your helmet using an alcohol pad (Fig. 1).
2. Position the mount over your helmet to find an appropriate mounting position. In most cases the mount will line up with the center of the chin area but make sure to find helmet area where the mount perfectly contours the curve of the helmet (Fig. 2, 3).
3. Once the mounting area has been located, peel back the VHB adhesive and heat up the adhesive with a blow dryer or a heat gun so it is warm (Not hot). (Fig. 4, 5)
4. Sometimes it is possible for gaps to appear between the VHB adhesive and the surface of the helmet. This is caused by improper mount placement, to solve this we recommend heating up the area with a blow dryer on moderate heat and applying pressure onto the mount until it cools down.

In most cases this will solve the issue, but if it doesn't, do not worry as it's only visual and does not affect adhesion between the helmet and the mount in any way.

5. We recommend not putting any weight on the mount for at least 12 hours in order for the adhesive to fully cure, and make sure to test the mount with a camera attached over a soft surface (bed, couch) to make sure the mount will not detach itself before going for a ride.

