

CMM JK A-Pillar RAM Ball Mount

Installation Instructions

Thank you for purchasing the CMM JK A-Pillar RAM Ball Mount!

You will need: 13mm socket with an extension of at least 2 inches
5/16" Allen wrench

USE CAUTION WORKING NEAR THE WINDSHIELD!!

- STEP 1** This can be installed on the driver or passenger side. Placement can be the top of windshield frame outboard of the visor mount or in the A-Pillar upper opening.
- STEP 2** Decide which location and use the 13mm socket to remove the factory bolt.
- STEP 3** Reinstall our JK A-Pillar RAM Ball Mount and torque to 30 ft lbs. with the 5/16" Allen wrench
- If you have a sPod and/or a hands free mic, use caution to not crush the wires between the stanchion and the A-pillar frame.

ENJOY YOUR NEW JK A-Pillar RAM Ball Mount!

If you have any technical questions, please feel free to call: (704) 213-4319

