

JL A-Pillar Base with 1" or 20mm Ball Mount



Installation Instructions

Thank you for purchasing the CMM Offroad JL A-Pillar Base

You will need: 10mm socket and ratchet
5mm and 8mm Allen Wrenches
Flat Blade Screwdriver or Trim removal Tool

Step 1 Start on the drivers side and remove the upper or lower cover plate from the A Pillar Handle with the flat Blade Screwdriver or Trim Removal Tool.



Step 2 Use a 10mm Socket to remove the bolt inside the handle.



Step 3 Install the Mount into the handle and tighten the provided bolt with a 5mm Allen.



Step 4 Carefully re-install the 1" or 20mm Ball mount and tighten with an 8 mm allen wrench. Do not exceed 180 in/lbs.



Step 5 Repeat this process on the passengers side.

If you have any technical questions, email tech@cmmoffroad.com or call: (704) 213-4319