

CMM JL A-Pillar Mirror and 1" Ball Mount Installation Instructions

Thank you for purchasing the CMM JL A-Pillar Mirror and 1" Ball Mount

You will need: 10mm socket and ratchet
5mm and 8mm Allen Wrenches
Flat Blade Screw Driver or Trim removal Tool

Step1 Start on the drivers side and remove the upper cover plate from the A Pillar Handle with the flat Blade Screw Driver or Trim Removal Tool.



Step 2 Use an 10mm Socket to remove the bolt inside the handle.



Step 3 Install the Mount that has the red dot into the handle and tighten the provided bolt with a 5mm Allen.



Step 4 Carefully re-install the 1" Ball mount and tighten with an 8 mm allen wrench. Do not exceed 180 in/lbs.



Step 5 Repeat this process on the passengers side. Note the passenger side has NO red dot.



You are now ready to install your CMM Offroad Side Mirrors and drive comfortably without the doors on your JL!

