

CMM JL/JT Freedom Panel Ball Mount

Thank you for purchasing the CMM JL Accessory Mount

You will need: T-40 Torx
8mm Allen Wrench

1. Use your T-40 Torx to take out the factory freedom panel lever bolt.
2. Install CMM Ball bolt with 8mm Allen Wrench.
3. Attach desired device with 1' ball mount accessory.

