

# CMM JKU BILLET REAR GRAB HANDLE

## Installation Instructions

Thank you for purchasing the CMM Billet Grab Handles!

You will need: 10mm socket with an extension of at least 2 inches  
8mm Allen wrench  
1/4" Allen wrench

STEP 1 Start on the drivers side and remove the front bolt that secures the sound bar to the roll cage with the 10mm socket.

STEP 2 Install one of the 4 stanchions into this hole using the 8mm Allen wrench socket. Install to hand tight and then 1/2 to 3/4 turn more. **DO**

STEP 3 **NOT** over tighten. 100 in./lbs is recommended. Repeat steps 1 and 2 for the rear bolt in the sound bar.

STEP 4 Locate the main bar marked DS (Drivers Side). Using 2 of the supplied 5/16 x 18 socket head cap screws, attach the main bar to the 2 previously installed stanchions. The stanchions will fit into the large counterbores in the main bar with the bolts going into the small counterbore side. Tighten to 12 ft/lbs.

STEP 5 Mount the handle to the main bar using 2 of the supplied 5/16 x 18 socket head cap screws.

STEP 6 Repeat this process for the passenger side.

ENJOY YOUR NEW CMM BILLET GRAB HANDLES!

If you have any technical questions, please feel free to call: (704) 213-4319

