

CMM JL Accessory Mount

Thank you for purchasing the CMM JL Accessory Mount

You will need: 10mm socket and ratchet

6mm and 9/64" Allen Wrenches

Flat Blade Screw Driver or Trim removal Tool

1. Remove the factory plastic cover from the center trim.
2. Using a 10mm socket, remove the factory mounting bolt.
3. The base for the accessory mount is indexed to fit into the plastic only one way.
The fin in the plastic corresponds to the cutout in the mount base.
4. Push the Mount Base into the recess and install 6mm bolt using the 6mm Allen. Firmly snug.
5. Now you can mount the riser plate with the 8-32 screws. Angle plate can also be installed in the desired position.

