

CMM RAM Truck Universal Accessory Mount

Thank you for purchasing the CMM RAM Truck Universal

Accessory Mount You will need:

6mm and 9/64" Allen Wrenches

10mm socket and ratchet

1. Remove the factory plastic cover from the center trim.
2. Using a 10mm socket, remove the factory mounting bolt.
3. The base for the accessory mount is indexed to fit into the plastic only one way.
The fin in the plastic corresponds to the cutout in the mount base.
4. Push the Mount Base into the recess and install 6mm bolt using the 6mm Allen. Firmly snug.
5. Now you can mount the riser plate with the 8-32 screws. Angle plate can also be installed in the desired position.

