

CMM TJ/LJ Billet Grab Handle Installation Instructions

Thank you for purchasing the CMM Billet Grab Handles!

You will need: 1/4" Allen wrench
1/8" Allen wrench
Hack saw or sharp knife
Duct Tape

USE CAUTION WORKING NEAR THE WIND SHIELD!!

There are many different configurations for the TJ/LJ (1997 to 2006). We are covering the general installation and your application may vary slightly.

- STEP 1** Start on the drivers side and remove the door surround.
- STEP 2** On the earlier models, 97', 98, etc., the roll bar padding is not removable without disassembling the roll cage. On these models the front portion of cloth, ahead of the front door surround mounting point, will need to be cut off. See Pic 1 and pic 2 below.
- STEP 3** On the newer models, unzip and remove the padding cover and carefully remove the padding from the roll bar. It is held to the roll bar with plastic push pins. Evenly pull it away from the bar using care to not break the padding. Once removed, see pic 3 and pic 4 for location to cut padding.
- STEP 4** Wrap duct tape around the roll cage in an area about 1 inch back from the windshield to 4 inches back from the windshield. Pic 5
- STEP 5** "Snap" the tube clamp around the roll bar using the duct tape to protect the paint on the roll bar. Once it is on the bar REMOVE the duct tape. Pic 6
- STEP 6** Locate a handle, 2-5/16 bolts and a saddle. Bring the saddle up between the 2 sides of the tube clamp and insert the 2 bolts from inside the jeep toward the door thru the clamp side, thru the saddle and thru the other clamp side. Raise the handle and loosely thread the bolts into the handle. Refer to sheet 3 for handle position options.
- STEP 7** Reinstall the roll bar padding, door surrounds and etc.. Rotate and position handle to suit your preference and also to allow clearance for the door surround, hard top, door, etc.
- STEP 8** Once in position, fully tighten both 5/16 bolts evenly to 30 ft/lbs. Then insert 1/8" wrench thru hole in bottom of saddle and tighten set screw.
- STEP 9** On the newer models, the cloth cover will go back on the roll cage bar. Feed the handle thru the front surround hole and back up into place. Position it so the door surround will fit back in and zip it up. Pic 9 and pic 10
- STEP 10** Repeat on passenger side.

ENJOY YOUR NEW CMM BILLET GRAB HANDLES!

If you have any technical questions, please feel free to call: (704) 213-4319

Pic 1



Pic 2



Pic 3



Pic 4



Pic 5



Pic 6



Pic 7



Pic 8



Pic 9



Pic 10

