

## SIDE COVERS - 375

### PARTS INCLUDED:

- SIDE COVER LEFT SIDE ————— 1
- SIDE COVER RIGHT SIDE ————— 1
- RUBBER ACCENT LEFT SIDE ———— 1
- RUBBER ACCENT RIGHT SIDE ——— 1
- ADHESIVE PROMOTER(PRIMER) — 2

1. PARK ON A LEVEL SURFACE AND SHUT OFF THE MOTORCYCLE.

2. CLEAN THE MOUNTING SURFACE WITH HOT WATER AND SOAP TO REMOVE ALL DIRT AND DEBRIS.

3. ATTENTION: THOROUGHLY CLEAN THE MOUNTING SURFACE WITH DENATURED ALCOHOL TO REMOVE ALL WAX, OIL, AND RESIDUE.

**\*NOTE: DO NOT INSTALL IF THE TEMPERATURE IS BELOW 50° F. THE ADHESIVE WILL NOT CURE PROPERLY.**

4. APPLY THE ADHESION PROMOTER ACCORDING TO THE INSTRUCTION ON ITS CONTAINER ONTO LEFT AND RIGHT SIDE MOUNTING LOCATIONS.

5. REMOVE THE RED ADHESIVE BACKING AND INSTALL THE COVERS. PRESS THE COVERS FIRMLY ONTO THE SURFACE FOR 60 SECONDS. THE ADHESIVE CURES WITHIN 24 HOURS.

6. ATTACH RUBBER ACCENTS TO EACH COVERS IF PREFER.

### WARNING:

IGNORING THE INSTRUCTION MAY RESULT IN POTENTIAL SERIOUS INJURY, DEATH OR MATERIAL DAMAGE.

### LIMITED WARRANTY:

PRODUCTS ARE WARRANTED TO BE FREE OF DEFECTS IN MATERIAL AND WORKMANSHIP FOR 1 (ONE) YEAR FROM DATE OF PURCHASE BY THE CONSUMER.

CUSTOMER MUST SHOW PROOF OF PURCHASE FOR WARRANTY.

TWINART SHALL NOT BE LIABLE FOR ANY CONSEQUENTIAL AND INCIDENTAL DAMAGES.

THE PRODUCTS MUST BE INSTALLED PROPERLY AND OPERATED UNDER NORMAL CONDITIONS.