

SADDLEBAG GUARD COVERS 325

PARTS INCLUDED:

SADDLEBAG GUARD COVER LEFT SIDE	1
SADDLEBAG GUARD COVER RIGHT SIDE	1
ALCOHOL PAD	2

WARNING:

IGNORING THE INSTRUCTION
MAY RESULT IN POTENTIAL
SERIOUS INJURY, DEATH
OR
MATERIAL DAMAGE.

LIMITED WARRANTY:

PRODUCTS ARE WARRANTED TO BE FREE OF DEFECTS IN MATERIAL AND WORKMANSHIP FOR 1 (ONE) YEAR FROM DATE OF PURCHASE BY THE CONSUMER.

CUSTOMER MUST SHOW PROOF OF PURCHASE FOR WARRANTY.

TWINART SHALL NOT BE LIABLE FOR ANY CONSEQUENTIAL AND INCIDENTAL DAMAGES.

THE PRODUCTS MUST BE INSTALLED PROPERLY AND OPERATED UNDER NORMAL CONDITIONS.

1. PARK ON A LEVEL SURFACE AND SHUT OFF THE MOTORCYCLE.

2. CLEAN THE MOUNTING SURFACE WITH HOT WATER AND SOAP TO REMOVE ALL DIRT AND DEBRIS.

3. ATTENTION: THOROUGHLY CLEAN THE MOUNTING SURFACE WITH DENATURED ALCOHOL TO REMOVE ALL WAX, OIL, AND RESIDUE.

***NOTE: DO NOT INSTALL IF THE TEMPERATURE IS BELOW 50° F. THE ADHESIVE WILL NOT CURE PROPERLY.**

4. THIS ITEM HAS LEFT AND RIGHT SIDE. CHECK THE SIDE BEFORE ADHERE.

THROTTLE SIDE IS A RIGHT SIDE

5. REMOVE THE RED ADHESIVE BACKING AND INSTALL THE COVERS. PRESS THE COVERS FIRMLY ONTO THE SURFACE FOR 60 SECONDS. THE ADHESIVE CURES WITHIN 24 HOURS.