



ECONOMY PERCH MOUNT

Parts Included:

- 1 Long Metric Ball Post
- 1 M6x1.0x30mm Set Screw
- 1 1/4" Split Lock Washer

Installation Instructions:

1. Park on a level surface and shut off the motorcycle. Ensure that the engine has had time to cool before installation.
2. Remove the M6 hand control clamp screw where you would like the perch mount to be located.
3. Assemble hardware with lock washer onto motorcycle, then tighten securely.



4. Install *Ciro* accessory on the ball mount, then check for tank clearance.



Note: There may be other locations you choose to install this mount.

WARNING:

This indication alerts you to the fact that ignoring the contents described herein can result in potential serious injury or death if not followed.

CAUTION:

This indication alerts you to the fact that ignoring the contents described herein can or will result in material damage and/or personal injury.

ATTENTION:

This indication alerts you to the fact if you ignore this detail you will affect the performance or functionality of the product.

All *Ciro* products are designed for "easy assembly" and/or "plug and play". We recommend a competent mechanic install our products, using standard mechanical procedures to assure a safe and successful installation.

NOTE:

Ciro products are designed and manufactured under very strict quality control. *Ciro* products are warranted to be free of defects in material and workmanship for 1 (one) year from date of purchase by the consumer.

Ciro will have no obligation if the customer cannot show proof of purchase.

Warranty will not be granted unless the part is properly installed and maintained.

Ciro will not be liable for any consequential and incidental damages, including labor, or non-*Ciro* products.

Please visit our website Ciro3d.com for our complete warranty policy.

CIRO3D.COM