



3/4" CLAMP ACCESSORY MOUNT

WARNING This indication alerts you to the fact that ignoring the contents described herein can result in potential serious injury or death if not followed.

CAUTION This indication alerts you to the fact that ignoring the contents described herein can or will result in material damage and/or personal injury.

ATTENTION This indication alerts you to the fact if you ignore this detail you will affect the performance or functionality of the product.

All Ciro products are designed for "easy assembly" and/or "plug and play". We recommend a competent mechanic install our products, using standard mechanical procedures to assure a safe and successful installation. Read completely and understand the instructions prior to starting installation.

NOTE: Ciro products are designed and manufactured under very strict quality control. Ciro warrants that products sold to the original purchaser shall be free from any defects in materials and workmanship for a period of 3 (three) years from the date of purchase, and a lifetime warranty against LED failure. Ciro will have no obligation if the customer cannot show proof of purchase. Warranty will not be granted unless the part is properly installed and maintained. Ciro will not be liable for any consequential and incidental damages, including labor, or non-Ciro products. Please visit Ciro3d.com for our complete warranty policy.

Installation Instructions:

Step 1 Park on a level surface, allow the vehicle to cool.

Note: Tightening this clamp onto a bar may mark the surface.

Step 2 Select location to install clamp, ensuring clearances to all surrounding components, and that the section of tubing is straight. Avoid mounting on bends.

Step 3 Clean the mounting surface with an amonia based cleaner to remove debris and waxes.

Step 4 Position the male half of the clamp (Fig.1) onto the bar. This half of the clamp will be on the opposite side of the ball post.

Step 5 Slide the female half of the clamp (Fig.1) over the hook of the male half of the clamp, aligning the screw holes of the clamp halves.

Step 6 Insert the screw through the clamp halves, going through the male half first.

Step 7 Thread the ball post onto the screw so that it is only finger tight.

Step 8 Fine tune the position of the clamp and ball post assembly, then fully tighten the screw and ball post. **Do not overtighten.** Do not exceed 7-10 ft-lbs.

Note: There will be a small gap between the clamp halves when it is properly installed. Fig.2.

Note: If you have purchased a Ciro accessory to go with the Clamp Mount, please refer to the instructions included with that product to complete installation.

Items Included:

3/4" Female Clamp Half
3/4" Male Clamp Half
Ball Post
1/4-20 x 3/4" Screw



Fig.1

Female clamp half



Fig.2

