



GOLDSTRIKE GRIPS

Parts Included:	1	Left grip half w/logo
	1	Left grip half
	1	Right grip half w/logo
	1	Right grip half
	2	End caps
	1	Hardware Kit

INSTALLATION INSTRUCTIONS:

1. Park on a level surface and shut off the motorcycle. Lift motorcycle onto its center stand if available. Ensure the engine has time to cool before installation.
2. Use a large #3 phillips screwdriver to remove the bar end weights. (FIG.1)
3. Clean the left and right hand grips on your motorcycle with hot water and soap to remove all dirt and debris.
4. Test fit the GOLDSTRIKE grips to familiarize yourself with how they fit. The grip half with the round end and threaded hole goes on the bottom. The seam between the two halves should be approximately parallel to the ground. (FIG.3,4)
NOTE: This product is assembled so the GOLDSTRIKE logo is on the top. If you prefer not to see the logos you can remove the rubber inserts and swap them left to right. Double check that the rubbers are correctly installed.
5. ATTENTION: Thoroughly clean the mounting surfaces with denatured alcohol to remove all wax, oil, and residue.
NOTE: New motorcycles are delivered from the factory covered in protective oil. Remove it before installing this product.
NOTE: Do not install if the temperature is below 50° F. The adhesive will not cure properly. (FIG.2)
6. Install the bottom half first. Check that the rubber is installed into the frame correctly. Carefully peel back the adhesive liner and press the parts into place with the mating surface approximately parallel to the ground. (FIG.4)



FIG.1



FIG.2




FIG.3



FIG.4

WARNING:
This indication alerts you to the fact that ignoring the contents described herein can result in potential serious injury or death if not followed.

CAUTION:
This indication alerts you to the fact that ignoring the contents described herein can or will result in material damage and/or personal injury.

ATTENTION:
This indication alerts you to the fact if you ignore this detail you will affect the performance or functionality of the product.

All Ciró products are designed for "easy assembly" and/or "plug and play". We recommend a competent mechanic install our products, using standard mechanical procedures to assure a safe and successful installation.

NOTE:
Ciro products are designed and manufactured under very strict quality control. Ciró warrants that products sold to the original purchaser shall be free from any defects in materials and workmanship for a period of 3 (three) years from the date of purchase, and a lifetime warranty against LED failure. Ciró will have no obligation if the customer cannot show proof of purchase. Warranty will not be granted unless the part is properly installed and maintained. Ciró will not be liable for any consequential and incidental damages, including labor, or non-Ciró products. Please visit our website Ciro3d.com for our complete warranty policy.

7. To install the top half, carefully peel back the adhesive liner and press the parts into place so they line up with the bottom half. Press firmly on the rubbers to ensure full contact.

8. Install the end cap with a M3x12 SHCS using a 2.5mm hex wrench. Leave it a little loose. (FIG.5)

9. Carefully pull up on the corners of the inner flange and install a M3x12 SHCS on the front and back of the grip. **DO NOT OVER TIGHTEN.** (FIG.6)

NOTE: Hold the center of the flange with one finger and pull the rubber with your thumb. (FIG.6)

10. Tighten the end cap. **DO NOT OVER TIGHTEN.**

11. Repeat steps 4-10 on the other side.

NOTE: If the rubber part of your grip is not set in place correctly, use a credit card or other thin plastic tool to help work the rubber into place. Glass cleaner can work as a lube that will help you get the rubber in place and it dries without remaining slippery.

