



PASSENGER PHONE MOUNT FOR GOLDWING

- WARNING** This indication alerts you to the fact that ignoring the contents described herein can result in potential serious injury or death if not followed.
- CAUTION** This indication alerts you to the fact that ignoring the contents described herein can or will result in material damage and/or personal injury.
- ATTENTION** This indication alerts you to the fact if you ignore this detail you will affect the performance or functionality of the product.

All Giro products are designed for "easy assembly" and/or "plug and play". We recommend a competent mechanic install our products, using standard mechanical procedures to assure a safe and successful installation. Read completely and understand the instructions prior to starting installation.

NOTE: Giro products are designed and manufactured under very strict quality control. Giro warrants that products sold to the original purchaser shall be free from any defects in materials and workmanship for a period of 3 (three) years from the date of purchase, and a limited lifetime warranty against LED failure. Giro will have no obligation if the customer cannot show proof of purchase. Warranty will not be granted unless the part is properly installed, unmodified and maintained. Giro will not be liable for any consequential and incidental damages, including labor, or non-Giro products. Please visit Ciro3d.com for our complete warranty policy.



Note: Goldstrike armrest required for installation of Passenger Phone Mount

Installation Instructions:

1. Park on a level surface, allow the motorcycle to cool.
2. Install on the right side of the motorcycle. Remove plug or accessory from the passenger armrest. Insert mount into armrest with the slot at the top as shown in Fig. 1. Once inserted all the way rotate 90 degrees clockwise. Tighten bolt with 4mm hex wrench. Fig. 2
3. Insert the carriage bolt through the arm, put a plastic washer between the arm and mount, followed by the other plastic washer, then the metal washer and locknut. Order shown in Fig.3.
4. Tighten locknut so the arm has some friction when pivoting. Assembly should be tight enough to not move when in use but still allow for passenger adjustments if necessary. Periodically check tightness of hardware to maintain adequate friction.
5. Install phone holder following its provided instructions.
6. Removal of Passenger Phone Mount is opposite of installation.

CAUTION There is a two pound weight limit for the arm and accessory. Never use the phone mount as a hold when boarding the motorcycle. Periodic checking of fasteners to ensure tightness and performance of the pivot is required.

