

# GOLDSTRIKET MIRROR TRIM

1

1

Parts Included:

Left mirror trim Right mirror trim

#### WARNING:

This indication alerts you to the fact that ignoring the contents described herein can result in potential serious injury or death if not followed.

# CAUTION:

This indication alerts you to the fact that ignoring the contents described herein can or will result in material damage and/or personal injury.

## ATTENTION:

This indication alerts you to the fact if you ignore this detail you will affect the performance or functionality of the product.

All Ciro products are designed for "easy assembly" and/or "plug and play". We recommend a competent mechanic install our products, using standard mechanical procedures to assure a safe and successful installation.

## NOTE:

Ciro products are designed and manufactured under very strict quality control. Ciro warrants that products sold to the original purchaser shall be free from any defects in materials and workmanship for a period of 3 (three) years from the date of purchase, and a lifetime warranty against LED failure. Ciro will have no obligation if the customer cannot show proof of purchase. Warranty will not be granted unless the part is properly installed and maintained.

- Ciro will not be liable for any
- consequential and incidental
- damages, including labor, or
- non-Ciro products.
- Please visit our website
- Ciro3d.com for our complete warranty policy.

INSTALLATION INSTRUCTIONS:

- 1. Park on a level surface and shut off the motorcycle. Ensure the engine has time to cool before installation.
- 2. Clean the front and top of the mirrors with soap and hot water to remove all dirt and debris.
- 3. ATTENTION: Thoroughly clean the mounting surface with denatured alcohol to remove all wax, oil, and residue. NOTE: New motorcycles are delivered from the factory covered in protective oil. Remove it before installing this product. NOTE: Do not install if the temperature is below 50° F. The adhesive will not cure properly.
- 4. Test fit the mirror trim to familiarize yourself with its natural location. The mirror trim is designed to fit at the front edge of the rearview mirrors, above the turn signal lens. (Fig.3)
- 5. Place masking tape around the edge of the mirror trim so you can see where to install it. (Fig.1)(Fig.2)
- 6. Remove the red adhesive backing and install the mirror trim. Press the mirror trim firmly onto the surface for 60 seconds. The adhesive cures within 24 hours.





**Goldstrike3D.com** 

