

# HARDWIRE®

## Emergency Response Shield Resource Guide

---

### ERS DIMENSIONS

Size

18" X 20"

Weight

25 LBS

Material

STEEL

Protection Level 3+

*Stops shotguns,  
handguns, rifles, and  
Green Tip armor  
piercing ammunition.*



**FLAT SIDE  
FACES WALL**




**HANDLE SIDE  
FACES OUT**

---

### HARDWARE INCLUDED

1 Hanger - 2 Anchors - 2 Screws - 2 Tapcons



### ADDITIONAL TOOLS NEEDED

Power Drill - 5/32" Masonry Drill Bit - Phillips & Flathead Screwdrivers/ Drill Bits



### DISCLAIMER

The ERS weighs 25 pounds. Ensure the hanger is properly installed with the provided hardware on a wall or structure that can withstand the weight.

---

**For visual instruction, SCAN to learn!**

---

**INSTALLATION  
VIDEO**



**GENERAL  
TRAINING VIDEO**



**SCHOOL  
TRAINING VIDEO**



# ERS Installation Directions

## MASONRY

### TOOLS NEEDED:

- Power Drill
- 5/32" Masonry Drill Bit
- Flat Head Screwdriver/ Drill Bit

### HARDWARE INCLUDED:

- A - Fire Extinguisher Hanger (1)  
B - Tapcon Masonry Screws (2)



### MASONRY INSTALL STEPS:

1. Place hanger (A) on wall where you would like the ERS placed. Mark the hanger holes on the wall.
2. Drill 2.25" deep pilot hole with 5/32" masonry drill bit.
3. Position hanger on wall inline with pilot holes into the recently marked areas. Screw in tapcons with flathead bit.
4. Hang ERS on wall, handles facing out. Flat shield face is placed against the wall.

## DRYWALL

### TOOLS NEEDED:

- Power Drill
- Phillips Head Screwdriver/ Drill Bit

### HARDWARE INCLUDED:

- A - Fire Extinguisher Hanger (1)  
C - Screws (2)  
D - Drywall Anchors (2)



### DRYWALL INSTALL STEPS:

1. Place hanger (A) on wall where you would like the ERS placed. Mark the hanger holes on the wall. Make sure there is no stud.
2. Insert drywall anchor (D) straight into the recently marked areas on the wall with a phillips head drill bit.
3. Position hanger over anchors, insert screw (C) through hanger holes, into the anchors with the phillips head screwdriver. Tighten with drill or by hand.
4. Hang ERS on wall, handles facing out. Flat shield face is placed against the wall.

### DRYWALL STUD LOCATIONS:



1. Use a stud finder to locate the stud, Mark the 2 small hanger holes on the wall.
2. Drill a pilot hole with a 5/32" drill bit through the hole markings.
3. Placing the hanger over the pilot holes, insert the wood screws with the drill.
4. Hang ERS on wall, handles facing out. Flat shield face is placed against the wall.