

NEW RAGE CYCLES

INSTALLATION INSTRUCTIONS

ALTA ENDURO/SUPERMOTO

FENDER ELIMINATOR

- 1 Under tail, remove (5) Philips head screws (picture 1)
- 2 Unplug all connectors and remove plastic shield (picture 2)
- 3 Mount 'NRC' license plate bracket to turn signal bracket (picture 3)
- 4 Plug in all connectors prior to mounting kit on bike
 - Tail light connections:
 - Black to Black NRC spade
 - Yellow to Red NRC spade
 - Purple to Orange NRC spade
- 5 Test turn signals and brake light to make sure everything works properly
- 6 With provided M5x25 bolts and spacers, mount tail light onto bike (picture 4)
- 7 With (2) stock Philips head screws, use on remaining two lower holes (picture 5)
- 8 Zip tie harness around lens bracket (picture 6)
- 9 Tighten all bolts
- 10 **Product comes with 22ohm resistor. Wiring instructions are on bag.**

