

NEW RAGE CYCLES

INSTALLATION INSTRUCTIONS

BMW R9T

FRONT TURN SIGNALS

- 1 Unbolt stock turn signal with T30 torx (picture 1)
- 2 Unscrew lens on stock signal (picture 2)
- 3 Unplug stock connectors and slide out of stock signal (picture 3)
- 4 With provided shrink tube, slide over wires, plug NRC turn signal into stock harness and shrink tube your connections (picture 4)
 - Brown wire Black NRC wire
 - Blue wire Red NRC wire
- 5 Using stock bolt, install new blinker with T30 torx and zip tie your wires

