

NEW RAGE CYCLES

INSTALLATION INSTRUCTIONS

BMW R1200R

FRONT TURN SIGNALS

- 1 Remove screw on stock signals and pop off lens (picture 1)
- 2 Slide out housing and disconnect both spade connectors (picture 2)
- 3 Remove stock signal housing by unbolting (1) bolt (picture 3)
- 4 Unscrew top plate from new turn signals and with stock bolt, re-use to install top plate (picture 4)
- 5 Slide wires through hole and screw lens onto top plate (picture 5)
- 6 Slide provided shrink tubing over connectors and plug spade connectors together
 - Brown wire to Black NRC wire
 - Blue wire to Red NRC wire
- 7 Test your turn signals BEFORE you seal the shrink tubing
- 8 Zip tie wires if necessary

