

NEW RAGE CYCLES

INSTALLATION INSTRUCTIONS

KAWASAKI Z900 (2017-PRESENT)

FRONT TURN SIGNALS

- 1 Remove wind screen with a 4mm allen key (picture 1)
- 2 Unplug (2) OEM connectors
- 3 Remove (1) philips head screw, remove plate, and slide off stock blinker (picture 2)
- 4 Signals are right/left specific. Photo 3 is left blinker and photo 4 is right blinker installed as if you were sitting at the bike; not looking at the bike (pictures 3/4)
- 5 To begin installation, remove screw and separate flat bracket from blinker
- 6 Feed connector and small tab bracket through hole, sandwich the blinker and tighten philips head screw (pictures 5/6)
- 7 Repeat for other side
- 8 Plug connectors back into OEM harness
- 9 Reinstall wind screen

