

NEW RAGE CYCLES

INSTALLATION INSTRUCTIONS

YAMAHA XSR

FRONT TURN SIGNALS

- 1 Remove two 5mm allen bolts from headlight, one on each side (picture 1)
- 2 Unplug the headlight and put aside (picture 2)
- 3 Find the black and grey connectors, and unplug (picture 3)
- 4 Lift two rubber tags and remove plastic lock on stock signals (picture 4)
- 5 Remove two phillips head screws and take off plastic nut from new turn signals (picture 5)
- 6 Feed NRC wires through holes on backside of headlight and mount turn signal to the bike -- reinstall phillips head screws to previously removed plastic nut (picture 6)
- 7 Plug in NRC connectors to stock connectors
- 8 Reinstall headlight

