FITTING INSTRUCTIONS: Wrap-Around Roller shutter seal (WS014)

Tools required:

- Tape measure
- A pair of sharp scissors / stanley knife
- Pencil

Kit includes:

- Wrap Around seal
- Fitting instructions



Yellow Product Design Ltd.

sales@weatherstop.co.uk

Orchard House, 17 Summerwood Lane, Halsall, Ormskirk, Lancashire. L39 8RG (01704) 532 360 www.weatherstop.co.uk

The Wrap-Around Thermoplastic Bottom Seal, fits all standard 75mm T-bar bottom sections of commercial roller doors. It is very quick and easy to fit with no fixings/ sealant is required.

NB - It is important to follow instructions carefully. The bottom seal should be fitted by a mature adult.

STEP ONE

With a tape measure, measure the bottom of the roller doors

STEP TWO

Mark with a pencil the exact length of thermoplastic seal that needs to be cut in order to fit the opening. Use scissors to cut the door seal to size.

STEP THREE

With the garage door half open and working from one end, press and clip on one side of the flap. Repeat this process along the length of the seal. (USEFUL TIP Another person holding the other end of the seal will make the task much easier!)

STEP FOUR

Working from one end pull the other flap back and pull it over the T-bar bottom sections on the roller door. Repeat this process all the way along until the seal is fully connected on the T-bar.

STEP FIVE

Close the Roller Shutter and make sure the door shuts and is locking correctly.

Note: Due to coiling, there may be a 'ripple' effect along the bottom of the seal. Please allow a few days with product in situ and it will return to its original extruded shape.







