

# 19+ Ranger A-Pillar (Ditch) Light/Bracket Installation Instructions

## Step 1:

Open your hood. Carefully remove the 2 bolts that hold the hood to the latch, while continuing to support and hold the hood AGAINST the latch with one hand, while sliding the bracket over the posts with the other. (For safety, ONLY do one side at a time)

Once the bracket is over the posts, put the lock nuts back on one at a time and tighten them back down. Notice the photo. The Brackets are directional, so be sure you put the correct one on the correct side. They should angle OUTWARD.



## Step 2:

Install your lights with the factory hardware. Slide the bolts through the top hole, and install the washers and nut. Adjust and tighten. (See Pics)



## Optional A-Pillar Harness-

If you choose our optional A-Pillar Harness, or get a kit that includes it, (Shown to right) it will easily plug into your lights on each side with the various optional adapter plugs to fit any light. No need to cut and splice wire. These harnesses are cut to a proper length, with a little room, but not too much excess. The harnesses are professionally made and look OEM. For most Ranger applications, you will want to choose the RELAY adapter with fuse. For the Tremor package, with switches built in, you won't need that.

Notice the photo below. You can cleanly run your harness from one side to the other under the underhood heat shield. Then run it down the hood hinge.

