

Floating Divan (Split) - Assembly instruction

Diagram

The two grey sections are the main divan frame (foot end shown with rounded corners), with 4 slats (2 per half) underneath, the slats are the blue sections. The plinth position is shown as the red broken/dotted lines, with two slats that run down the length, plinth slats shown in black. Highlighted in yellow are the locations on where the screws need to be attached.

- Remove packaging.
- Locate & remove the kit bag containing the fittings, this will include 8 screws to attach the plinth.
- Place the two halves of divans (main section) face down, showing the underside.
- The head end will have four square corners and two slats, one at each end:
 - One will be approximately 7cm from the edge; this is the head end.
 - One at the opposite end but set in by approximately 20cm, this is the edge that connects to the foot end.
- Foot end has two square + two round corners, the rounded end is the foot end of the divan. It will also have two slats – One each end, both will be set in by approximately 20cm.
- Once you have located the head & foot end, while they are still face down, place them touching end to end.
- Place the plinth onto the faced down divans making sure it sits flush to the head end and centralised.
- This will give a 20cm overlap on the sides and foot end.
- The plinth has slats running down each length, using the 8 provided attach 4 screws into each side, making sure there is one screw per slat as per diagram.
- Carefully lift, turn and place the divan down the correct way up.
- Headboard hole locations will be marked with 'Insert Here' stickers.

Head End

