

BSP TO NPT CONVERSION INSTRUCTIONS

Adapting a UK shower for use in the US requires the installation of a suitable plumbing adapter to facilitate the smooth compatibility and interaction between US and UK components. Please see the instructions below for guidance on adapting your shower.

Whilst the installation process is straightforward, it is advisable to consider seeking assistance from a professional when installing your shower.

INSTALLATION

Please refer to the images below for guidance on fitting the BSP to NPT converter.

- 1. Included within your package will be the necessary number of brass BSP to NPT adapters for your chosen shower.
- 2. When installing your shower, at the base (water inlets) (A) please unscrew the compression nut / nuts (B).
- **3.** Now screw the BSP to NPT converter to the thread that has been uncovered by removing the compression nut from the inlet elbow / elbows on your shower (**C**).
 - **4.** Please ensure that the adapter has been securely fitted.

Your shower inlets are now ready for NPT fittings.





