

GET THE LOOK :

②

use 1/4" thick
island panel
to cover cabinet
sides, including
gap at the back.



①

pull taller cabinets forward
with plain lumber behind

③

Finish off with decorative
end panels and trim molding
as per your design.