

## ASSEMBLY INSTRUCTIONS AeroTote for Tesla Model 3

Please read these Installation Instructions <u>BEFORE</u> you assemble and use EVANNEX AeroTote. Detailed video installation instructions can be found at evannex.com.

EVANNEX AeroTote has been designed as a carrying case for your Model 3 Aero wheel covers. It provides the covers with protection and allows you to store and move them easily and efficiently.

## **ASSEMBLY**

- Step 1. Remove AeroTote from its wrapping, spread the sides open, and unzip the top zipper.
- Step 2. Pull out the three (3) dividers inside AeroTote and set them aside.
- Step 3. Rotate the AeroTote floor (base) downward so that it lies flat. AeroTote is designed to stand on the floor (base) with the handles on top as shown in the first photo on the right.
- Step 4. Locate the three (3) velcro strips on the innner sides of AeroTote. These three strips are used to attach each of the dividers. See the second photo on the right.
- Step 5. Taking the dividers one at a time, position the velcro strip on the divider next to the velcro strip on the inner side of AeroTote and press it into place. Do this on both sides of each divider. See the third photo on the right.
- Step 6. Repeat step 5 for all three dividers.

**AreoTote is now assembled,** and you can place the Aero wheel covers into each of the compartments created by the dividers. See photo below this text. We recommend that you orient all Aero wheel covers in the same direction.

AeroTote is now ready for use!







