

## INSTALLATION INSTRUCTIONS EVANNEX HEADLIGHT "EYEBROWS" FOR MODEL 3 & MODEL Y

Copyright © 2020 - 2021 EVANNEX®, All rights reserved.

Please read these installation instructions BEFORE you attempt to apply the vinyl kit.

Installation of our Headlight "Eyebrows" is made relatively easy because we use transfer tape as a top layer.

However, if you're uncomfortable with Vinyl Kit installation for any reason, we recommend that you contact a professional vinyl installer at an automotive custom shop or window tinting outlet and have that person do the installation.

An installation video for this product can be found at evannex.com. Note: The video and these Installation Instructions depict a Model 3 install. The approach for Model Y is identical.

## INSTALLATION

We recommend doing this work in a dust free environment in which the temperature is at least 72 degrees F.

Step 1a. Wash your entire Model 3 or Model Y thoroughly. Be sure you have removed all dust, dirt, sand, and oil before proceeding further. Allow the vehicle to dry. Using a mixture of 40% isopropyl alcohol and 60 percent water, clean the entire glass headlight assembly. Be sure that all dust particles have been removed. This is very important for a good result.


Step 1b. Turn your headlights on. This provides better visibility for alignment.

Step 1c. Using a good scissors or a straight-edge and X-acto knife, cut the eyebrow sheet longitudinally, separating the driver and passenger-side pieces.

Step 2. Peel the transfer tape above the driver-side eyebrow vinyl from the white backing. The vinyl eyebrow will be removed and remain attached to the transfer tape. Do not to allow one part of the tape to touch another part.

Step 3. Hold both ends of the transfer tape and carefully align the inside edge of the vinyl with the glass edge of the passenger side headlight. Alignment should be about 1/8 in. (~3mm) from the edge of the glass, but do NOT touch the transfer tape to the glass.

Step 4. Once you're satisfied with your alignment, pull slightly on both ends of the transfer tape and at the same time lower it to the glass. Be sure that the vinyl does not have any waves in it as you lower the transfer tape.



Step 6. Peel the transfer tape up <u>slowly</u> on the diagonal being sure that the vinyl remains adhered to the headlight glass. The tip of the vinyl may stay adhered to the transfer tape. If that happens, use your finger nail to pull it off the transfer tape and press it down onto the glass. Then pull the transfer tape off along a diagonal.

Step 7. Using your finger, the vinyl squeegee (provided) and a gentle touch, smooth any bubbles or wrinkles, always moving toward the outside edges of the vinyl. If bubbles or wrinkles are persistent, you may have to peel up the vinyl part way (be certain not to stretch the vinyl) and reapply to eliminate bubbles or wrinkles.

Repeat steps 2 through 7 for the passenger side headlight assembly.

Your installation is complete.

## RETURNS

Like all EVANNEX® products, you may return the Eyebrow Vinyl Kit <u>unopened and unused</u> for a period of 30 days from delivery. You must have an RMA number for proper processing of a return. <u>The cost of return packaging and shipping is your responsibility</u>. However, once the white backing has been removed from any Vinyl Kit piece, <u>the entire vinyl kit to which it belongs can no longer be returned for credit or exchange</u>. Therefore, <u>please be certain that you're satisfied with the look and style of your Vinyl Kit BEFORE</u> you remove the backing from any Vinyl Kit piece.