



INSTALLATION INSTRUCTIONS Foot Rest Dead Pedal Cover

Please read these installation instructions **BEFORE** you install the EVANNEX Foot Rest Dead Pedal Cover.

These instructions cover installation of the EVANNEX Foot Rest Dead Pedal for all Tesla Model 3, Model S, and Model X vehicles. Please be sure you follow the steps outlined for your vehicle.

Installation of the EVANNEX Foot Rest Dead Pedal Cover is a relatively straightforward DIY project. However, if you're uncomfortable with the steps outlined for any reason, we recommend that you contact a professional installer at an automotive custom shop and have them do the installation.

Video installation instructions are available at evannex.com.

Tesla Model 3 —Installation Steps

Step 1. Thoroughly clean the rubberized, ribbed foot rest location. All dirt, dust, and oil should be removed. Use a gentle household cleaner to start. We recommend using a 40% isopropyl alcohol-60% water mixture as your final cleaning step.

NOTE: If your Model 3 has tight weave carpeting covering the footrest, the EVANNEX Foot Rest Dead Pedal should NOT be installed. Return it to EVANNEX for a refund.

Step 2 [Optional]. Leaving the red adhesive backing in place, fit the slots in the EVANNEX Foot Rest Dead Pedal Cover over the OEM rubber ribs in the foot rest area. Be sure you familiarize yourself with placement and that all ribs protrude through the slots cut into the cover.

Step 3. Remove the red adhesive backing, exposing the adhesive.

Step 4. Carefully place the EVANNEX Foot Rest Dead Pedal Cover over the OEM rubber ribs in the foot rest area. Press down hard along the metal next to each of the rubber ribs to promote a strong adhesive bond. Press down hard at the top and bottom of the cover.

Your installation is complete.

Tesla Model S —Installation Steps

Step 1. Thoroughly clean the rubberized foot rest location. All dirt, dust, and oil should be removed. Use a gentle household cleaner to start. We recommend using a 40% isopropyl alcohol-60% water mixture as your final cleaning step.

Step 2 [Optional]. Leaving the adhesive backing in place, position the EVANNEX Foot Rest Dead Pedal Cover in the foot rest area. Find a location that satisfies your eye.

Step 3. Remove the adhesive backing, exposing the adhesive.

Step 4. Carefully place the EVANNEX Foot Rest Dead Pedal Cover in the foot rest area. Be sure that the embossed "Model S" is properly oriented. Press down hard to promote a strong adhesive bond.

Your installation is complete.

Tesla Model X —Installation Steps

Step 1. Thoroughly clean the tight weave carpeting in the foot rest location. All dirt and dust should be removed using a vacuum cleaner, if possible.

Step 2 [Optional]. Leaving the adhesive backing in place, position the EVANNEX Foot Rest Dead Pedal Cover in the foot rest area. Find a location that satisfies your eye.

Step 3. Remove the adhesive backing, exposing the adhesive.

Step 4. Carefully place the EVANNEX Foot Rest Dead Pedal Cover in the foot rest area. Be sure that the embossed "Model X" is properly oriented. Press down hard to promote a strong adhesive bond.

Your installation is complete.

EVANNEX® — Tesla Aftermarket Accessories
www.evannex.com

Disclaimer: Evannex is not responsible for any vehicle damage caused during the installation or use of this product. Any costs associated with any vehicle damage are the sole responsibility of the purchaser.