



INSTALLATION INSTRUCTIONS

GLOVE BOX ORGANIZER FOR MODEL 3 & MODEL Y

Copyright © 2021 EVANNEX®, All rights reserved.

Please read these installation instructions **BEFORE** you assemble and install the EVANNEX Glove Box Organizer.

INSTALLATION

Step 1. Slide Part C into the slot in Part D until it is all the way forward as shown in Figure 1. The angled edge of Part C should be on the bottom side.

Step 2. Slide Part A onto the left (driver-side) edge of Part D. The curved edge of Part A should be on the upper side.

Step 3. Slide Part B onto the right (passenger-side) edge of Part D. The curved edge of Part B should be on the upper side.

Step 4. Slide the assembled Glove Box Organizer (Figure 2) into the glove box.

Your installation is complete.

