



## INSTALLATION INSTRUCTIONS

### Qi WIRELESS CHARGER FOR MODEL 3 (OWL)

Please read these installation instructions **BEFORE** you install the EVANNEX® Qi Wireless Charger (OWL).

EVANNEX OWL (On-board Wireless Layer) is a custom-designed Qi wireless charger for your Model 3. It allows Model 3 owners to charge two mobile devices (that have wireless charging circuitry or use a wireless charging case) by placing those devices on the charger.

Installation of EVANNEX OWL is a simple DIY project. However, if you're uncomfortable with the installation for any reason, we recommend that you contact a professional installer and have them do the installation for you.

**Video installation instructions are available at [evannex.com](http://evannex.com).**

**Step 1. Open the OEM charging door, the storage door, and lift the OEM charging shelf to expose the OEM ports beneath the shelf.** Remove any stored items temporarily and pull any USB connectors that you were using for wired charging. You can leave the mini-connectors in place on the shelf. For neatness, we recommend using a 'twisty' to secure the existing USB cabling.



**Step 2. Rotate the OEM charging shelf downward and remove the OEM light grey, rubberized charging platform cover by pulling it upward.** We recommend storing it in a safe place.

**Step 3. Remove any existing USB charging cable(s) and mini-connector(s)** by sliding the gloss OEM 'bumper' at the bottom of the platform to the left. Then remove the cable by pulling it out of its cradle and along the channel in the platform.

**Step 4. Remove EVANNEX OWL from its box and remove the twisties from both of its USB cables.** Thread the cables through the opening in the OEM charging shelf (see photo).

**Step 5. Move OWL into position on the OEM charging platform while at the same time pulling the OWL cabling through so that the OWL sits flat on the OEM charging platform.**

**Step 6. Plug in the OWL USB connectors.** Use the 'twisties' provided to gather up excess USB cabling for neatness.

**Step 7. Test your device using OWL.**  
*Your installation is complete.*

EVannex® — Tesla Aftermarket Accessories

3413 SW 14th Street •• Deerfield Beach, FL 33442 •• [www.evannex.com](http://www.evannex.com)

Disclaimer: Evannex is not responsible for any vehicle damage caused during the installation or use of this product. Any costs associated with any vehicle damage are the sole responsibility of the purchaser.



## TROUBLESHOOTING:

**Every OWL has been tested BEFORE it is shipped and is certified to work properly and provide appropriate charging.** If your device is not charging, here are some potential areas to investigate:

- 1. Verify that your mobile device is Qi charging capable.** If it is not, you'll need to purchase a Qi charging case designed specifically for your device.
- 2. If you've never tried Qi charging on your Qi capable device or a device with a Qi charging case, try to charge the device on another Qi charger to verify that there is no defect in your device or your charging case.**
- 3. Make sure you've placed your device directly over one of the Qi chargers** and that it lies flat on the Qi charger.
- 4. Verify that the USB plugs are fully seated and that your USB ports are working properly.** First, use a standard USB cable, and plug in your device. If it works, the ports are working properly. Next, pull out and re-plug the OWL USB connectors. Try OWL again.
- 5. Be sure that the OWL USB cables have not been cut or broken during installation** (unlikely, but possible).

If you've tried all of these things and you still get no charge, contact us for next steps.

## REMOVING OWL:

**Step 1. Unplug the OWL USB connectors and remove the 'twisties' from the cables.**

**Step 2. Tilt OWL upward slightly** (you can pull it upward using the small slot between the two chargers), **then pull the OWL cable through the opening.**

**Step 3. Replace the OEM light grey, rubberized charging platform, and plug in your wired charging USB cable.**