

## Trunk Organizer<sup>™</sup> for Model 3 and Model Y Installation Instructions

Thanks for purchasing Trunk Organizer for Model 3 and Model Y. Please read these installation instructions in their entirety BEFORE you attempt to install Trunk Organizer.

Trunk Organizer has been designed to provide an organized storage solution for the trunk well of your Model 3 or Model Y.

**DISCLAIMER:** Trunk Organizer is installed by placing it into the trunk well of the Model 3 or Model Y trunk. This installation is quite simple and does not require any tools or measurement. However, EVANNEX® is NOT responsible for any damage and/or repair or replacement costs associated with the installation and/or any residual damage that might occur during installation or later use of Trunk Organizer.

## **Quick Start Installation Steps:**

Tools required: none

Step 1. Remove Trunk Organizer from its shipping container.



**Step 2.** Release the two buckles and open the trunk organizer body. Fold out the walls of ther trunk organizer, recognizing that they are not perpendicular but have been designed to fit the unique dimensions of the Model 3 and Model Y trunk well. Place the handles outside the body. Note that the ends of the organizer body are soft (to enable folding) and may buckle inward slightly.



Step 3. Position the two dividers (shipped at the bottom of the body) along the Velcro strips that run the entire length of the organizer. IMPORTANT: Note that the Velcro is "sticky" so care must be taken to position the dividers so they sit along the bottom and sides of the organizer.



Step 4. Tilt the trunk well lid upward and place the Trunk Organizer into the trunk well. The EVANNEX logo should face toward the rear.

Step 5. Fill the Trunk Organizer with the items you want stored and replace the trunk lid.

Installation is complete!

## **IMPORTANT NOTE:**

1. **Do not attempt to lift a fully loaded Trunk Organizer out of the trunk well.** Doing so can damage it. Remove your stored items and then remove Trunk Organizer.

