

**Directions:** For glue down method. Recommended.

1. Prepare your sub floor so that it is free of all dust, dirt, grease or other foreign material. Also when gluing your flooring down, it is recommended that the sub floor is free of any moisture.
2. Loose lay out the rolls in the area as you would like them to look after a complete installation. The rolls can be directional so make sure the color matches on each rolls. If the colors do not appear to match, flip them or turn them 180 degrees to ensure color matches. Allow the rubber flooring to acclimate to the room temperature 24-48 hours.
3. Make any necessary cuts to the rolls to fit them into the area using a straight edge and a Utility knife with a fresh blade.
4. Roll up the rolls at one end of the room. Put down a ten foot long light layer of adhesive and unroll ten feet of the flooring into the adhesive at a time. Repeat this step for every ten feet of roll length until the entire roll has been unrolled into its desired position.
5. After all rolls have been glued down, it is often recommended to use a 100 pound roller on the floor in order to guarantee good adherence to the sub floor..

***Note: The black raw material used to manufacture the product is a recycled material, with no dyes or colorants added, and as such there can be minor variations in the intensity of the black color.***

**Directions:** For Tape Installation

1. Prepare your sub floor so that it is free of all dust, dirt, grease or other foreign material.
2. Loose lay out the rolls in the area as you would like them to look after a complete installation. The rolls can be directional so make sure the color matches on each rolls. If the colors do not appear to match, flip them or turn them 180 degrees to ensure color matches. Allow the rubber flooring to acclimate to room temperature 24-48 hours.
3. Make any necessary cuts to the rolls to fit them into the area using a straight edge and a Utility knife with a fresh blade.
4. Apply double sided tape to perimeter of each roll.
5. Place rubber rolls back into position on top of the double sided tape.